WAC 296-307-45045 Protect employees during welding, burning, or other work using open flames.

You must:

- Make sure the dip tank and the area around it are thoroughly cleaned of solvents and vapors before performing work involving:
 - Welding
 - Burning

OR

- Open flames.

Reference:

There are additional requirements for this type of work. See Welding, cutting and brazing, WAC 296-307-475, and Respirators, chapter 296-307 WAC, Part Y-5.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 05-01-166, \$ 296-307-45045, filed 12/21/04, effective 4/2/05; WSR 03-10-068, \$ 296-307-45045, filed 5/6/03, effective 8/1/03.]