- WAC 296-307-52043 What requirements apply to loading powered industrial trucks? (1) All loads must be stable or safely arranged. Exercise caution when handling off-center loads that cannot be centered.
 - (2) All loads must be within the rated capacity of the truck.
- (3) Take care securing, manipulating, positioning, and transporting loads when attachments are used. Trucks with attachments must be operated as partially loaded trucks when not handling a load.
- (4) Place the load carrier under the load as far as possible. Tilt the mast backward to stabilize the load.
- (5) Use extreme care when tilting the load forward or backward, particularly when high tiering. Avoid tilting the load forward with the load carrier elevated except to pick up a load, or when the load is in a deposit position over a rack or stack. When stacking or tiering, use only enough backward tilt to stabilize the load.

[WSR 97-09-013, recodified as § 296-307-52043, filed 4/7/97, effective 4/7/97. Statutory Authority: RCW 49.17.040, [49.17.]050 and [49.17.]060. WSR 96-22-048, § 296-306A-52043, filed 10/31/96, effective 12/1/96.]