WAC 296-806-42046 Guard wheels and rails on mobile conveyors. You must install sweeps in front of the nip points created by the wheels and rails to deflect objects that could derail the conveyor.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-42046, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-42046, filed 6/29/04, effective 1/1/05.]