- WAC 296-56-60039 Dockboards (bridge plates). (1) You must use portable and powered dockboards strong enough to carry the load imposed.
- (2) You must secure portable dockboards in position, either by being anchored or equipped with devices which will prevent slipping.
- (3) You must design and construct powered dockboards in accordance with commercial standards CS202-56 (1956) *Industrial Lifts and Hinged Loading Ramps* published by the United States Department of Commerce.
- (4) You must provide handholds or other effective means on portable dockboards to permit safe handling.
- (5) You must provide positive protection to prevent railroad cars from being moved while dockboards or bridge plates are in position.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-56-60039, filed 12/1/15, effective 1/5/16. Statutory Authority: RCW 49.17.040 and 49.17.050. WSR 86-03-064 (Order 86-02), § 296-56-60039, filed 1/17/86; WSR 85-01-022 (Order 84-24), § 296-56-60039, filed 12/11/84.]