WAC 296-307-26006 Definitions that apply to this section. Nose or nosing. The part of a tread projecting beyond the face of the riser immediately below.

**Open riser.** The air space between the treads of stairways without risers.

**Platform.** An extended step or landing breaking a continuous run of stairs.

**Railing.** A vertical barrier erected along exposed sides of stairways and platforms to prevent people from falling. The top part of the railing usually serves as a handrail.

**Rise.** The vertical distance from the top of a tread to the top of the next higher tread.

**Riser.** The upright part of a step at the back of a lower tread and near the leading edge of the next higher tread.

**Stairs or stairway.** A series of steps. A series of steps and landings having three or more risers constitutes stairs or a stairway.

**Tread.** The horizontal part of a step.

**Tread run.** The horizontal distance from the leading edge of a tread to the leading edge of an adjacent tread.

**Tread width.** The horizontal distance from front to back of tread, including nosing.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050 and 49.17.060. WSR 21-04-128, § 296-307-26006, filed 2/2/21, effective 3/8/21. WSR 97-09-013, recodified as § 296-307-26006, filed 4/7/97, effective 4/7/97. Statutory Authority: RCW 49.17.040, [49.17.]050 and [49.17.]060. WSR 96-22-048, § 296-306A-26006, filed 10/31/96, effective 12/1/96.]