

WAC 296-150C-0300 When is design-plan approval required? Design plans for commercial coaches are required for units that are sold, leased, or used in Washington state and must be approved when:

- (1) You build a new unit;
- (2) You modify an approved design plan through addendums;
- (3) You add options to an approved design plan through addendums;

or

- (4) You change the occupancy classification of the building.

[Statutory Authority: RCW 43.22.340, [43.22.]355, [43.22.]360, [43.22.]432, [43.22.]440 and [43.22.]480. WSR 96-21-146, § 296-150C-0300, filed 10/23/96, effective 11/25/96.]