WAC 296-807-15025 Make sure powder loads and power levels are properly identified. You must make sure powder loads and power levels are identified as specified in Table 3, Powder-Load Identification

	Power Level	Color Identification	
		Case Color	Load Color
Lowest Level	1	Brass	Gray
	2	Brass	Brown
	3	Brass	Green
	4	Brass	Yellow
	5	Brass	Red
	6	Brass	Purple
	7	Nickel	Gray
	8	Nickel	Brown
	9	Nickel	Green
	10	Nickel	Yellow
Highest power level	11	Nickel	Red
	12	Nickel	Purple

Table 3 Powder-Load Identification

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-807-15025, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, [49.17].040, [49.17].050, and [49.17].060. WSR 03-09-009, § 296-807-15025, filed 4/4/03, effective 8/1/03.]