- WAC 296-835-12005 Include additional safeguards when constructing dip tanks. (1) You must make sure the dip tank, drain boards (if provided), and supports, are made of noncombustible material.
- (2) You must make sure piping connections on drains and overflow pipes allow easy access to the inside of the pipe for inspection and cleaning.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-18-075, § 296-835-12005, filed 9/5/17, effective 10/6/17. Statutory Authority: RCW 49.17.010, [49.17].040, and [49.17].050. WSR 02-15-102, § 296-835-12005, filed 7/17/02, effective 10/1/02.]