

**WAC 296-807-15005 Make sure tool operators are qualified. (1)**

You must make sure tools are used only by qualified operators.

(2) You must make sure operators have been trained by an authorized instructor.

**Note:** Authorized instructors have to meet the instructor qualifications of ANSI A10.3-1995, Safety Requirements for Powder-Actuated Fastening Systems.

(3) You must make sure all tool operators can:

(a) Understand the manufacturer's instructions;

(b) Clean the tool properly;

(c) Recognize any visibly worn or damaged parts;

(d) Identify power load levels;

(e) Operate the tool correctly.

(4) You must make sure tool operators have a valid qualified operator's card in their possession when they are using the tool.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-807-15005, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, [49.17].040, [49.17].050, and [49.17].060. WSR 03-09-009, § 296-807-15005, filed 4/4/03, effective 8/1/03.]