

WAC 296-400A-030 Do I need a temporary permit? You need a temporary permit if you are an active out-of-state journey level plumber, domestic pump specialty plumber, or a residential specialty plumber residing in a state that does not have a reciprocal agreement with Washington and you would like to work as a plumber in Washington. Temporary permits are not issued for installers of medical gas piping systems.

Temporary permits are not issued for the backflow assembly maintenance and repair specialty. Therefore, WAC 296-400A-030 through 296-400A-033 do not apply to this specialty.

[Statutory Authority: Chapter 18.106 RCW and Uniform Plumbing Code. WSR 16-08-100, § 296-400A-030, filed 4/5/16, effective 5/16/16. Statutory Authority: RCW 18.106.040, 18.106.140. WSR 06-24-040, § 296-400A-030, filed 11/30/06, effective 12/31/06. Statutory Authority: RCW 18.106.040, 18.106.140, 2002 c 82, and 2003 c 399. WSR 04-12-046, § 296-400A-030, filed 5/28/04, effective 6/30/04. Statutory Authority: RCW 18.106.040, 18.106.140, 2001 c 281, and chapter 18.106 RCW. WSR 02-14-074, § 296-400A-030, filed 6/28/02, effective 7/1/02. Statutory Authority: Chapter 18.106 RCW. WSR 98-13-126, § 296-400A-030, filed 6/17/98, effective 7/20/98. Statutory Authority: RCW 18.106.050, [18.106.]070, [18.106.]110, [18.106.]125, [18.106.]140 and [18.106.]270. WSR 97-11-052, § 296-400A-030, filed 5/20/97, effective 6/30/97.]