

**WAC 296-870-20020 Obstructions and slipping hazards.** (1) You must prohibit the accumulation of tools, materials and debris on the platform that are not related to the work in progress.

(2) You must make sure stabilizer ties are:

(a) Located to allow movement along the full length of the platform without interference; and

(b) Long enough not to become entangled in rollers, hoists, or other machinery.

(3) You must prohibit employees from working on platforms covered with snow, ice, or other slippery material.

**EXEMPTION:** Employees may be on platforms as necessary to remove the slipping hazard.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-870-20020, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 47.17.060. WSR 06-19-075, § 296-870-20020, filed 9/19/06, effective 1/1/07.]