

WAC 296-150C-1200 Installation instructions. The manufacturer must provide printed instructions upon request for each commercial coach specifying the following:

- (1) The location and required capacity of stabilizing devices, such as tie downs, piers, and blocking;
- (2) Devices and methods used to connect all components and systems including, chassis and utilities; and
- (3) Leveling, including releveling.

[Statutory Authority: RCW 43.22.340, [43.22.]355, [43.22.]360, [43.22.]432, [43.22.]440 and [43.22.]480. WSR 96-21-146, § 296-150C-1200, filed 10/23/96, effective 11/25/96.]