

WAC 296-874-30020 Make sure wire rope clips are used properly.

- (1) You must make sure, if wire rope clips are used on suspended scaffolds, such as on the suspension ropes or support lines, that:
 - (a) A minimum of three clips are installed;
 - (b) The distance between clips is at least six rope diameters;
 - (c) Clips are installed according to the manufacturer's recommendations.
- (2) You must retighten the clips to the manufacturer's recommendations after the initial loading.
- (3) You must inspect the clips and retighten them to the manufacturer's recommendations at the start of each work shift.
- (4) You must make sure U-bolt clips are not used at the point of suspension for any scaffold hoist.
- (5) You must make sure, if U-bolt clips are used, that:
 - (a) The U-bolt is placed over the dead end of the rope; and
 - (b) The saddle is placed over the live end of the rope.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-874-30020, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 05-01-054, § 296-874-30020, filed 12/7/04, effective 3/1/05.]