

WAC 296-878-13005 Inspect the area to be cleaned. (1) You must inspect the building before cleaning to make sure there are no areas that can damage worker fall protection equipment and window-cleaning equipment. Inspect:

- (a) Sharp edges of parapets;
- (b) Window frames;
- (c) Open projected windows;
- (d) Cornices;
- (e) Overhangs;
- (f) Any other areas that may abrade, sever, weaken, or damage the equipment.

(2) You must make sure all working surfaces are safe and free from hazards such as:

- (a) Grease;
- (b) Oil;
- (c) Other slippery substances.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060, and chapter 49.17 RCW. WSR 14-09-095, § 296-878-13005, filed 4/22/14, effective 7/1/14. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 02-22-027, § 296-878-13005, filed 10/28/02, effective 1/1/03.]