

WAC 173-186-360 Planning standards for air monitoring to protect oil spill responders and the public. Rail contingency plans shall include a narrative description of applicable federal, state, and local requirements and the plan holder's resources for conducting air monitoring to protect oil spill responders and the public, including:

(1) A description of how initial site characterization for responders will occur;

(2) A description of air monitoring instruments and detection limits that will be used when monitoring for public safety;

(3) A description of action levels for various oil constituents of concern based on products handled by the railroad (benzene, H₂S, etc.);

(4) A description of how data management protocols and reporting time frames will be managed under unified command;

(5) A description of how communication methods to at-risk populations will be managed under unified command;

(6) A description of how evacuation zones and shelter-in-place criteria are established under unified command.

[Statutory Authority: RCW 90.56.210. WSR 16-18-052 (Order 15-14), § 173-186-360, filed 8/31/16, effective 10/1/16.]