

WAC 296-835-12050 Keep the area around dip tanks clear of combustible material and properly dispose of waste. (1) You must make sure the area surrounding dip tanks is:

- (a) Completely free of combustible debris;
- (b) As free of combustible stock as possible.

(2) You must provide approved metal waste cans that are:

- (a) Used for immediate disposal of rags and other material contaminated with liquids from dipping or coating operations;
- (b) Emptied and the contents properly disposed of at the end of each shift.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-18-075, § 296-835-12050, filed 9/5/17, effective 10/6/17. Statutory Authority: RCW 49.17.010, [49.17].040, and [49.17].050. WSR 02-15-102, § 296-835-12050, filed 7/17/02, effective 10/1/02.]