

WAC 296-806-42012 Provide backstop or antirunaway devices on incline, decline, or vertical conveyors. You must make sure all incline, decline, or vertical conveyors use backstop or antirunaway devices when there is a danger of conveyor reversal or runaway.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-42012, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-42012, filed 6/29/04, effective 1/1/05.]