

WAC 296-835-11045 Protect employees during welding, burning, or other work using open flames. You must make sure the dip tank and the area around it are thoroughly cleaned of solvents and vapors before performing work involving:

- (1) Welding;
- (2) Burning; or
- (3) Open flames.

Reference: There are additional requirements for this type of work. See Welding, cutting and brazing, chapter 296-24 WAC, Part I, and Respiratory protection, chapter 296-842 WAC.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-18-075, § 296-835-11045, filed 9/5/17, effective 10/6/17; WSR 05-03-093, § 296-835-11045, filed 1/18/05, effective 3/1/05. Statutory Authority: RCW 49.17.010, [49.17].040, and [49.17].050. WSR 02-15-102, § 296-835-11045, filed 7/17/02, effective 10/1/02.]