

WAC 296-807-15010 Make sure employees are aware tools are in use and wear appropriate personal protective equipment (PPE). (1) You must make sure eye or face protection is worn by:

- (a) Tool operators;
- (b) Assistants;
- (c) Persons close to where the tool is being used.

(2) You must post signs where tools are being used and in adjacent areas where tool use could pose a hazard. Signs must:

- (a) Be easily seen;
- (b) Be at least 8 x 10 inches (20 x 25 cm);
- (c) Use letters in boldface type at least one inch (2.5 cm) high;
- (d) Read "POWDER ACTUATED TOOL IN USE" or similar wording.

Note: Tool use could create a hazard in adjacent areas by allowing a fastener to penetrate one or more of the following:
1. Wall;
2. Floor;
3. Other working surface.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-807-15010, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 07-03-163, § 296-807-15010, filed 1/24/07, effective 4/1/07; WSR 03-09-009, § 296-807-15010, filed 4/4/03, effective 8/1/03.]