

WAC 296-52-67245 High speed tunneling: Central primer house.

Note: The following requirements apply when primers are made up at a central primer house for use in high speed tunneling:

- (1) **Primers.**
 - (a) Only enough primer must be made for each round of blasting.
 - (b) Primers must be placed in separate containers and bins, categorized by the degree of delay in preventing physical impact.
- (2) **Separation of explosives in magazines.** Explosives transported in the same magazine must be separated by:
 - (a) One-quarter inch steel; and
 - (b) Covered on each side by four inches of hardwood planking or equivalent protection.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-16-132, § 296-52-67245, filed 8/1/17, effective 9/1/17. Statutory Authority: RCW 49.17.010, [49.17].040, and [49.17].050. WSR 02-03-125, § 296-52-67245, filed 1/23/02, effective 3/1/02.]