

**WAC 296-807-14010 Prevent air tools from ejecting attachments.
You must make sure the tool cannot accidentally eject an attachment.**

Note: A retainer is needed if the tool does not have a positive method of keeping the attachment in the tool.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-807-14010, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, [49.17].040, [49.17].050, and [49.17].060. WSR 03-09-009, § 296-807-14010, filed 4/4/03, effective 8/1/03.]