

WAC 296-807-15005 Make sure tool operators are qualified. (1)

You must make sure tools are used only by qualified operators.

(2) You must make sure operators have been trained by an authorized instructor.

Note: Authorized instructors have to meet the instructor qualifications of ANSI A10.3-1995, Safety Requirements for Powder-Actuated Fastening Systems.

(3) You must make sure all tool operators can:

(a) Understand the manufacturer's instructions;

(b) Clean the tool properly;

(c) Recognize any visibly worn or damaged parts;

(d) Identify power load levels;

(e) Operate the tool correctly.

(4) You must make sure tool operators have a valid qualified operator's card in their possession when they are using the tool.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-807-15005, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, [49.17].040, [49.17].050, and [49.17].060. WSR 03-09-009, § 296-807-15005, filed 4/4/03, effective 8/1/03.]