

WAC 296-307-45550 Keep the area around dip tanks clear of combustible material and properly dispose of waste.

You must:

- (1) Make sure the area surrounding dip tanks is:
 - Completely free of combustible debris
 - As free of combustible stock as possible.
- (2) Provide approved metal waste cans that are:
 - Used for immediate disposal of rags and other material contaminated with liquids from dipping or coating operations
 - Emptied and the contents properly disposed of at the end of each shift.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 03-10-068, § 296-307-45550, filed 5/6/03, effective 8/1/03.]