

WAC 296-400A-031 How do I qualify for a temporary permit? To qualify for a temporary permit, you must:

(1) Have an active state-issued journey level plumber, domestic pump specialty plumber, or a residential specialty plumber certificate;

(2) Give the department sufficient qualifying evidence for a journey level plumber, domestic pump specialty plumber, or a residential specialty plumber certificate of competency;

(3) Never have taken the journey level plumber, domestic pump specialty plumber, or a residential specialty plumber competency examination in Washington state; and

(4) Not be a trainee or an apprentice plumber.

[Statutory Authority: Chapter 18.106 RCW and Uniform Plumbing Code. WSR 16-08-100, § 296-400A-031, filed 4/5/16, effective 5/16/16. Statutory Authority: RCW 18.106.040 and 18.106.140. WSR 09-10-080, § 296-400A-031, filed 5/5/09, effective 6/5/09; WSR 06-24-040, § 296-400A-031, filed 11/30/06, effective 12/31/06. Statutory Authority: RCW 18.106.040, 18.106.140, 2002 c 82, and 2003 c 399. WSR 04-12-046, § 296-400A-031, filed 5/28/04, effective 6/30/04. Statutory Authority: RCW 18.106.040, 18.106.140, 2001 c 281, and chapter 18.106 RCW. WSR 02-14-074, § 296-400A-031, filed 6/28/02, effective 7/1/02. Statutory Authority: Chapter 18.106 RCW. WSR 98-13-126, § 296-400A-031, filed 6/17/98, effective 7/20/98. Statutory Authority: RCW 18.106.050, [18.106.]070, [18.106.]110, [18.106.]125, [18.106.]140 and [18.106.]270. WSR 97-11-052, § 296-400A-031, filed 5/20/97, effective 6/30/97.]