

WAC 296-806-20006 Arrange work areas to avoid creating hazards.

(1) You must make sure work areas around machinery are designed with enough space so each operator:

(a) Can clean and handle material without interference from other workers or machines.

(b) Does **not** have to stand in the way of passing traffic.

(2) You must provide enough space so employees can bring in and remove materials safely.

Reference: For requirements that apply to Aisles and passageways, see WAC 296-24-73505.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-20006, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-20006, filed 6/29/04, effective 1/1/05.]