

**WAC 296-806-47004 Safeguard nip points of roll-forming and bending machines.** (1) You must safeguard in-running nip points on roll-forming and bending machines with **at least one** of the following:

- (a) A point-of-operation guard or device.
- (b) An emergency stop device.

(2) You must [use] an emergency stop device [must be used] when a point-of-operation guard or device is not feasible.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-47004, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-47004, filed 6/29/04, effective 1/1/05.]