

WAC 296-835-13030 Control liquid spray over an open surface cleaning or degreasing tank. You must control the spray to the greatest extent feasible by:

- (1) Enclosing the spraying operation as completely as possible; and
- (2) Using mechanical ventilation to provide enough inward air velocity to prevent the spray from leaving the vapor area.

Note: Mechanical baffles may be used to help prevent the discharge of spray.

Reference: Spray painting operations are covered in Spray finishing using flammable and combustible materials, WAC 296-24-370, and Spray-finishing operations, WAC 296-62-11019.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-18-075, § 296-835-13030, filed 9/5/17, effective 10/6/17. Statutory Authority: RCW 49.17.010, [49.17].040, and [49.17].050. WSR 02-15-102, § 296-835-13030, filed 7/17/02, effective 10/1/02.]