

**WAC 296-150T-0300 When is design plan approval required?** Design plans for factory-built temporary worker housing structures prior to installation at the building site in Washington must be approved when:

- (1) You build a new unit;
- (2) You modify an approved design plan through an addendum; or
- (3) You add options to an approved design plan through an addendum.

[Statutory Authority: RCW 43.22.480. WSR 99-12-079, § 296-150T-0300, filed 5/28/99, effective 6/28/99.]