

WAC 296-803-50040 Meet these requirements if it is necessary to temporarily energize a machine, equipment, or component for testing or positioning. You must follow your normal energy control procedures to:

- (1) Remove the lockout or tagout devices.
- (2) Energize the machine, equipment, or component.
- (3) Reapply the lockout or tagout devices when testing or positioning is completed.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-18-075, § 296-803-50040, filed 9/5/17, effective 10/6/17; WSR 04-15-105, § 296-803-50040, filed 7/20/04, effective 11/1/04.]