

WAC 296-806-43016 Use die keys and shims made of proper-grade material. You must make sure that die keys and shims are made from a grade of material that will not easily crack or splinter.

Note: Die keys and shims should not project more than two inches in front and four inches in back of the ram or die.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-43016, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-43016, filed 6/29/04, effective 1/1/05.]