

WAC 296-869-20035 Workplace survey. You must have the operator survey the area, before using an aerial lift, for hazards such as:

- (1) Untamped earth fills;
- (2) Ditches;
- (3) Drop-offs and floor obstructions;
- (4) Debris;
- (5) Overhead obstructions and electrical conductors;
- (6) Weather conditions;
- (7) Unauthorized persons in the area.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-869-20035, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 06-19-073, § 296-869-20035, filed 9/19/06, effective 1/1/07.]