

WAC 296-307-45550 Keep the area around dip tanks clear of combustible material and properly dispose of waste. (1) The employer must make sure the area surrounding dip tanks is:

- (a) Completely free of combustible debris;
- (b) As free of combustible stock as possible.

(2) The employer must provide approved metal waste cans that are:

- (a) Used for immediate disposal of rags and other material contaminated with liquids from dipping or coating operations;
- (b) Emptied and the contents properly disposed of at the end of each shift.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 20-21-091, § 296-307-45550, filed 10/20/20, effective 11/20/20; WSR 03-10-068, § 296-307-45550, filed 5/6/03, effective 8/1/03.]