

WAC 296-807-15015 Make sure tools are adequately designed and constructed. (1) You must make sure the tool meets the design and construction requirements of the American National Standards Institute (ANSI) standard ANSI A10.3-1995, Safety Requirements for Powder-Actuated Fastening Systems.

Note: There may be a statement on the tool or in the instruction manual indicating the tool meets the requirements of the appropriate ANSI standard. If in doubt, check with the manufacturer.

- (2) You must make sure each tool has:
- (a) Operator instructions and a tool service manual;
 - (b) Powder load and fastener chart;
 - (c) Service tools and accessories.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-807-15015, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, [49.17].040, [49.17].050, and [49.17].060. WSR 03-09-009, § 296-807-15015, filed 4/4/03, effective 8/1/03.]