

WAC 296-870-60005 Design. (1) You must make sure structural supports, tie-downs, tie-in guides, anchoring devices and any affected parts of the building included in the installation are designed by, or under the direction of, a registered professional engineer experienced in such design.

(2) You must make sure affected parts of the building are capable of sustaining all the loads imposed by the equipment.

(3) You must make sure exterior installations are capable of withstanding prevailing climatic conditions.

(4) You must make sure the affected parts of the building allow employees to use the equipment without being exposed to a hazardous condition.

(5) You must make sure the building design and installation provides:

- (a) Safe access to and egress from the equipment; and
- (b) Sufficient space to conduct maintenance of the equipment.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 17-01-119, § 296-870-60005, filed 12/20/16, effective 1/20/17. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-870-60005, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 06-19-075, § 296-870-60005, filed 9/19/06, effective 1/1/07.]