

**WAC 296-54-54720 Rigging—Molles.** (1) Molles must not be used as a temporary connection between two spliced eyes of a load-supporting running line. Double molles may be used on droplines only and single molles may be used on strawline.

(2) Molles must be as large as the pinhole will accommodate and have the loose ends rolled in.

[Statutory Authority: RCW 49.17.010, [49.17].040 and [49.17].050. WSR 99-17-117, § 296-54-54720, filed 8/18/99, effective 12/1/99.]