

WAC 296-806-42064 Provide slack-cable switches on hoists. You must provide and arrange slack cable switches to cut power to the drive and set the brake when the skip or counterweight hoisting ropes either:

- (1) Develop slack; or
- (2) Lose tension due to sticking in the guides, over travel, or for any other reason.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-42064, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-42064, filed 6/29/04, effective 1/1/05.]