

**WAC 296-806-45014 Guard cutting heads on turning lathes.** You must install hoods or shields that cover as completely as possible all cutting heads, whether or not they rotate.

**Note:** The hood or shield should be hinged to the machine so it can be moved to make adjustments.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-45014, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-45014, filed 6/29/04, effective 1/1/05.]