

**WAC 296-96-02715 Disconnecting means, hoistwayless elevators.**

Where the controller is located on the car, the disconnecting means shall be located adjacent to the controller. Auxiliary disconnect means shall be provided at the main landing when the main power supply disconnect means is mounted adjacent to the controller on the car.

[Statutory Authority: RCW 70.87.030. WSR 23-17-141, § 296-96-02715, filed 8/22/23, effective 10/2/23.]