

WAC 296-864-50010 Follow these procedures for demounting single-piece rim wheels. You must follow the relevant procedures in Table 4, Procedures for Demounting Single-Piece Wheel Components.

**Table 4
Procedures for Demounting Single-Piece Rim
Wheels**

During these times:	Then:
At all times.	Make sure mounting and demounting of the tire is done only from the narrow ledge side of the wheel.
When demounting rim wheels.	Make sure tires are completely deflated before demounting by removal of the valve core.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-864-50010, filed 12/1/15, effective 1/5/16; WSR 04-20-079, § 296-864-50010, filed 10/5/04, effective 2/1/05.]