

**WAC 296-807-15035 Make sure the tool is appropriate to the job.**

(1) You must use the lowest velocity class of tool and load that will properly set the fastener.

(2) You must use the proper shield, fixture, adaptor, or accessory that is:

(a) Suitable for the job;

(b) Recommended and supplied by the manufacturer.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-807-15035, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, [49.17].040, [49.17].050, and [49.17].060. WSR 03-09-009, § 296-807-15035, filed 4/4/03, effective 8/1/03.]