- WAC 365-230-330 Work practice standards. (1) Standards for renovation activities. Renovations must be performed by certified firms using certified renovators as directed under WAC 365-230-370. The responsibilities of certified firms are set forth under WAC 365-230-360 and the responsibilities of certified renovators are set forth under WAC 365-230-380.
- (a) Occupant protection. Firms must post signs clearly defining the work area and warning occupants and other persons not involved in renovation activities to remain outside of the work area. To the extent practicable, these signs must be in the primary language of the occupants. These signs must be posted before beginning the renovation and must remain in place and readable until the renovation and the postrenovation cleaning verification have been completed. If warning signs have been posted in accordance with 24 C.F.R. 35.1345 (b)(2) or 29 C.F.R. 1926.62(m), additional signs are not required by this section.
- (b) Containing the work area. Before beginning the renovation, the firm must isolate the work area so that no dust or debris leaves the work area while the renovation is being performed. In addition, the firm must maintain the integrity of the containment by ensuring that any plastic or other impermeable materials are not torn or displaced, and taking any other steps necessary to ensure that no dust or debris leaves the work area while the renovation is being performed. The firm must also ensure that containment is installed in such a manner that it does not interfere with occupant and worker egress in an emergency.
  - (i) Interior renovations. The firm must:
- (A) Remove all objects from the work area, including furniture, rugs, and window coverings, or cover them with plastic sheeting or other impermeable material with all seams and edges taped or otherwise sealed.
- (B) Close and cover all ducts opening in the work area with taped-down plastic sheeting or other impermeable material.
- (C) Close windows and doors in the work area. Doors must be covered with plastic sheeting or other impermeable material. Doors used as an entrance to the work area must be covered with plastic sheeting or other impermeable material in a manner that allows workers to pass through while confining dust and debris to the work area.
- (D) Cover the floor surface, including installed carpet, with taped-down plastic sheeting or other impermeable material in the work area six feet beyond the perimeter of surfaces undergoing renovation or a sufficient distance to contain the dust, whichever is greater. Floor containment measures may stop at the edge of the vertical barrier when using a vertical containment system consisting of impermeable barriers that extend from the floor to the ceiling and are tightly sealed at joints with the floor, ceiling, and walls.
- (E) Use precautions to ensure that all personnel, tools, and other items, including the exteriors of containers of waste, are free of dust and debris before leaving the work area.
  - (ii) Exterior renovations. The firm must:
- (A) Close all doors and windows within twenty feet of the renovation. On multistory buildings, close all doors and windows within twenty feet of the renovation on the same floor as the renovation, and close all doors and windows on all floors below that are the same horizontal distance from the renovation.
- (B) Ensure that doors within the work area that will be used while the job is being performed are covered with plastic sheeting or

other impermeable material in a manner that allows workers to pass through while confining dust and debris to the work area.

- (C) Cover the ground with plastic sheeting or other disposable impermeable material extending ten feet beyond the perimeter of surfaces undergoing renovation or a sufficient distance to collect falling paint debris, whichever is greater, unless the property line prevents ten feet of such ground covering. Ground containment measures may stop at the edge of the vertical barrier when using a vertical containment system.
- (D) If the renovation will affect surfaces within ten feet of the property line, the renovation firm must erect vertical containment or equivalent extra precautions in containing the work area to ensure that dust and debris from the renovation does not contaminate adjacent buildings or migrate to adjacent properties. Vertical containment or equivalent extra precautions in containing the work area may also be necessary in other situations in order to prevent contamination of other buildings, other areas of the property, or adjacent buildings or properties.
- (c) Prohibited and restricted practices. The work practices listed below are prohibited or restricted during a renovation as follows:
- (i) Open-flame burning or torching of painted surfaces is prohibited.
- (ii) The use of machines designed to remove paint or other surface coatings through high speed operation such as sanding, grinding, power planing, needle gun, abrasive blasting, or sandblasting, is prohibited unless such machines have shrouds or containment systems and are equipped with a HEPA vacuum attachment to collect dust and debris at the point of generation. Machines must be operated so that no visible dust or release of air occurs outside the shroud or containment system.
- (iii) Operating a heat gun on painted surfaces is permitted only at temperatures below 1,100 degrees Fahrenheit.
  - (d) Waste from renovations.
- (i) Waste from renovation activities must be contained to prevent releases of dust and debris before the waste is removed from the work area for storage or disposal. If a chute is used to remove waste from the work area, it must be covered.
- (ii) At the conclusion of each work day and at the conclusion of the renovation, waste that has been collected from renovation activities must be stored under containment, in an enclosure, or behind a barrier that prevents release of dust and debris out of the work area and prevents access to dust and debris.
- (iii) When the firm transports waste from renovation activities, the firm must contain the waste to prevent release of dust and debris.
- (e) Cleaning the work area. After the renovation has been completed, the firm must clean the work area until no dust, debris or residue remains.
  - (i) Interior and exterior renovations. The firm must:
- (A) Collect all paint chips and debris and, without dispersing any of it, seal this material in a heavy-duty bag.
- (B) Remove the protective sheeting. Mist the sheeting before folding it, fold the dirty side inward, and either tape shut to seal or seal in heavy-duty bags. Sheeting used to isolate contaminated rooms from noncontaminated rooms must remain in place until after the cleaning and removal of other sheeting. Dispose of the sheeting as waste.

- (ii) Additional cleaning for interior renovations. The firm must clean all objects and surfaces in the work area and within two feet of the work area in the following manner, cleaning from higher to lower:
- (A) Walls. Clean walls starting at the ceiling and working down to the floor by either vacuuming with a HEPA vacuum or wiping with a damp cloth.
- (B) Remaining surfaces. Thoroughly vacuum all remaining surfaces and objects in the work area, including furniture and fixtures, with a HEPA vacuum. The HEPA vacuum must be equipped with a beater bar when vacuuming carpets and rugs.
- (C) Wipe all remaining surfaces and objects in the work area, except for carpeted or upholstered surfaces, with a damp cloth. Mop uncarpeted floors thoroughly, using a mopping method that keeps the wash water separate from the rinse water, such as the two-bucket mopping method, or using a wet mopping system.
  - (2) Standards for postrenovation cleaning verification.
  - (a) Interiors.
- (i) A certified renovator must perform a visual inspection to determine whether dust, debris, or residue is still present. If dust, debris, or residue is present, these conditions must be removed by recleaning and another visual inspection must be performed.
- (ii) After a successful visual inspection, a certified renovator must:
- (A) Verify that each windowsill in the work area has been adequately cleaned, using the following procedure:
- (I) Wipe the windowsill with a wet disposable cleaning cloth that is damp to the touch. If the cloth matches or is lighter than the cleaning verification card, the windowsill has been adequately cleaned.
- (II) If the cloth does not match and is darker than the cleaning verification card, reclean the windowsill as directed in this section, then either use a new cloth or fold the used cloth in such a way that an unused surface is exposed, and wipe the surface again. If the cloth matches or is lighter than the cleaning verification card, that windowsill has been adequately cleaned.
- (III) If the cloth does not match and is darker than the cleaning verification card, wait for one hour or until the surface has dried completely, whichever is longer.
- (IV) After waiting for the windowsill to dry, wipe the windowsill with a dry disposable cleaning cloth. After this wipe, the windowsill has been adequately cleaned.
- (B) Wipe uncarpeted floors and countertops within the work area with a wet disposable cleaning cloth. Floors must be wiped using an application device with a long handle and a head to which the cloth is attached. The cloth must remain damp at all times while it is being used to wipe the surface for postrenovation cleaning verification. If the surface within the work area is greater than forty square feet, the surface within the work area must be divided into roughly equal sections that are each less than forty square feet. Wipe each such section separately with a new wet disposable cleaning cloth. If the cloth used to wipe each section of the surface within the work area matches the cleaning verification card, the surface has been adequately cleaned.
- (I) If the cloth used to wipe a particular surface section does not match the cleaning verification card, reclean that section of the surface as directed in this section, then use a new wet disposable cleaning cloth to wipe that section again. If the cloth matches the

cleaning verification card, that section of the surface has been adequately cleaned.

- (II) If the cloth used to wipe a particular surface section does not match the cleaning verification card after the surface has been recleaned, wait for one hour or until the entire surface within the work area has dried completely, whichever is longer.
- (III) After waiting for the entire surface within the work area to dry, wipe each section of the surface that has not yet achieved postrenovation cleaning verification with a dry disposable cleaning cloth. After this wipe, that section of the surface has been adequately cleaned.
- (iii) When the work area passes the postrenovation cleaning verification, remove the warning signs.
- (b) Exteriors. A certified renovator must perform a visual inspection to determine whether dust, debris or residue is still present on surfaces in and below the work area, including windowsills and the ground. If dust, debris or residue is present, these conditions must be eliminated and another visual inspection must be performed. When the area passes the visual inspection, remove the warning signs.
- (3) Optional dust clearance testing. Cleaning verification need not be performed if the contract between the renovation firm and the person contracting for the renovation or another federal, state, territorial, tribal or local law requires dust wipe sampling.
- (a) The renovation firm to perform dust clearance sampling at the conclusion of a renovation covered by this section.
- (b) The dust clearance samples are required to be collected by a certified inspector, risk assessor, or dust sampling technician.
- (c) The renovation firm is required to reclean the work area until the dust clearance sample results are below the clearance standards in WAC 365-230-020 or any applicable local standard.
- (4) Activities conducted after postrenovation cleaning verification. Activities that do not disturb paint such as applying paint to walls that have already been prepared, are not regulated by this subpart if they are conducted after postrenovation cleaning verification has been performed.

[Statutory Authority: RCW 70.103.030. WSR 14-03-104, § 365-230-330, filed 1/20/14, effective 2/20/14. Statutory Authority: RCW 70.103.10 [70.103.010], 70.103.20 [70.103.020], 70.103.30 [70.103.030], 70.103.40 [70.103.040], 70.103.50 [70.103.050], 70.10.80 [70.103.080], and 70.103.90 [70.103.090]. WSR 11-07-067, § 365-230-330, filed 3/21/11, effective 4/21/11.