- WAC 296-874-40032 Meet these requirements when using pump jack scaffolds. (1) You must make sure pump jack brackets, braces, and accessories are made from metal plates and angles.
- (2) You must make sure pump jack brackets have two positive gripping mechanisms to prevent any failure or slippage.
- (3) You must secure poles to the structure using rigid triangular bracing or the equivalent located at all of the following:
 - (a) Top;
 - (b) Bottom;
 - (c) Other points on the pole as necessary.
- (4) You must do both of the following when the pump jack has to pass bracing that's already installed:
- (a) Install an additional brace approximately four feet (1.2 m) above the brace to be passed.
 - (b) Leave it in place until:
 - (i) The pump jack has been moved; and
 - (ii) The original brace is reinstalled.
- (5) You must make sure work benches are not used as scaffold platforms.

Note: A work bench may be used as a toprail only if it meets the toprail requirements in Make sure guardrail systems meet these requirements, WAC 296-874-20064.

- (6) You must make sure wood poles used with pump jack scaffolds are:
 - (a) Straight grained; and
- (b) Free of shakes, large loose or dead knots, and other defects which might impair strength.
- (7) You must make sure wood poles that are constructed of two continuous lengths are joined together with the seam parallel to the bracket.
- (8) You must install a mending plate at all splices to develop the full strength of the member when splicing two by fours together to make a pole.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-874-40032, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 05-01-054, § 296-874-40032, filed 12/7/04, effective 3/1/05.]