## WAC 296-307-63210 Control employee noise exposures that equal or exceed 90 dBA TWAs.

## IMPORTANT:

Hearing protection provides a barrier to noise and protects employees but is not considered a control of the noise hazard. Separate requirements apply to hearing protection and are found in WAC 296-307-63215.

## You must:

· Reduce employee noise exposure, using feasible controls, wherever exposure equals or exceeds 90 dBA TWAs.

Note:

- Once noise exposures are brought below 90 dBA TWAs, no further reduction is required. However, further reduction of noise may reduce the need for other hearing loss prevention requirements
- Controls that eliminate noise at the source or establish a permanent barrier to noise are typically more reliable. For example:
- Replacing noisy equipment with quiet equipment
- Using silencers and mufflers
- Installing enclosures
- Damping noisy equipment and parts.
  Other controls and work practices may also be useful for reducing noise exposures. Examples include:
- Employee rotation
- Limiting use of noisy equipment
- Rescheduling work.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 05-01-166, § 296-307-63210, filed 12/21/04, effective 4/2/05.]