

*(Effective until March 1, 2022.)*

**WAC 246-215-05220 Design, construction and installation—Back-flow prevention device, design standard (2009 FDA Food Code 5-202.14).** A backflow or backsiphonage prevention device installed on a water supply system must meet American Society of Sanitary Engineering (A.S.S.E.) standards for construction, installation, maintenance, inspection, and testing for that specific application and type of device.

[Statutory Authority: RCW 43.20.050 and 43.20.145. WSR 13-03-109, § 246-215-05220, filed 1/17/13, effective 5/1/13.]

*(Effective March 1, 2022.)*

**WAC 246-215-05220 Design, construction and installation—Back-flow prevention device, design standard (FDA Food Code 5-202.14).** A backflow or backsiphonage prevention device installed on a water supply system must meet standards for construction, installation, maintenance, inspection, and testing for that specific application and type of device in accordance with WAC 246-290-490 and 51-56-0600.

[Statutory Authority: RCW 43.20.050 and 43.20.145. WSR 21-01-122, § 246-215-05220, filed 12/15/20, effective 3/1/22; WSR 13-03-109, § 246-215-05220, filed 1/17/13, effective 5/1/13.]